

#959 PARK/TAIL LIGHT POWER TO SWITCH

#907 HEADLIGHT POWER

MOPAR Headlight Switch

To have park lamps function as factory (parking lights turn off when headlights are on), hook the #927 wire to the "P" terminal.

#961 DOME LIGHT GROUND WIRE



#928 HEADLIGHT POWER TO SWITCH (POWER B+)



#929 TO REAR TAIL LIGHTS

#927 TO FRONT PARK LIGHTS



#930 INSTRUMENT PANEL LIGHTING