




2501 Ludelle Street
Fort Worth, Texas 76105
817-244-6212 Phone • 817-244-4024 Fax
888-350-6588 Sales • 800-423-9696 Tech
E-mail: support@painlessperformance.com
Web: www.painlessperformance.com

60140 & 60141-LS Coil Harness

This harness must be installed correctly or engine misfire will occur. All coil connectors have four wires, three of which are common between all coils (Black, Brown, and Pink). The fourth wire is the control wire, this wire color differs on all four coil connectors. Use the diagram to identify which coil each connector plugs into based on the color of the control wire found on the connector.



2501 Ludelle Street
Fort Worth, Texas 76105
817-244-6212 Phone • 817-244-4024 Fax
888-350-6588 Sales • 800-423-9696 Tech
E-mail: support@painlessperformance.com
Web: www.painlessperformance.com

60140 & 60141-LS Coil Harness

This harness must be installed correctly or engine misfire will occur. All coil connectors have four wires, three of which are common between all coils (Black, Brown, and Pink). The fourth wire is the control wire, this wire color differs on all four coil connectors. Use the diagram to identify which coil each connector plugs into based on the color of the control wire found on the connector.

