



2501 Ludelle Street
Fort Worth, Texas 76105
817-244-6212 Phone • 817-244-4024 Fax
888-350-6588 Sales • 800-423-9696 Tech
E-mail: painless@painlessperformance.com
Web: www.painlessperformance.com



Installation Instructions
For
#64440 Striker
Back Pressure
Sensor Eliminator

The Striker Back Pressure Sensor Eliminator features an ease of installation design. After one simple connection that annoying check engine light caused by a bad back pressure sensor will no longer be a problem. All current vehicle application instructions are included in this kit. Please read these entire instructions before beginning the installation. Make sure the key is off before any connections are made.

First, locate the sensor. It is located just in front of the fuel filter on the front of the engine. Remove the plastic cover just above the sensor.



Next, unplug the factory connector from the sensor. Plug in the eliminator into this factory connector. Use a tie wrap to hold the connector and eliminator away from the belt and pulleys.



Reinstall the plastic cover onto the engine. That is all there is to it.

Painless Performance Limited Warranty and Return Policy

Chassis harnesses and fuel injection harnesses are covered under a lifetime warranty. All other products manufactured and/or sold by Painless Performance are warranted to the original purchaser to be free from defects in material and workmanship under normal use. Painless Performance will repair or replace defective products without charge during the first 12 months from the purchase date. No products will be considered for warranty without a copy of the purchase receipt showing the sellers name, address and date of purchase. You must return the product to the dealer you purchased it from to initiate warranty procedures.