



2501 Ludelle Street  
Fort Worth, Texas 76105  
817-244-6212 Phone • 817-244-4024 Fax  
888-350-6588 Sales • 800-423-9696 Tech  
E-mail: [painless@painlessperformance.com](mailto:painless@painlessperformance.com)  
Web: [www.painlessperformance.com](http://www.painlessperformance.com)

## Installation Instructions For #64461 Striker Over Boost Code Eliminator

Make sure the key is off before any connections are made.

First, locate the boost pressure sensor. Look at the engine on the driver's side. It is located just to the left of the high pressure common fuel rail and behind the air intake horn.



Next, unplug the factory connector from the boost sensor. Plug in the male connector side of the Overboost code eliminator into this factory connector. Finally plug the factory connector into the female connector side of the Overboost code eliminator.



## **Painless Performance Limited Warranty and Return Policy**

Chassis harnesses and fuel injection harnesses are covered under a lifetime warranty. All other products manufactured and/or sold by Painless Performance are warranted to the original purchaser to be free from defects in material and workmanship under normal use. Painless Performance will repair or replace defective products without charge during the first 12 months from the purchase date. No products will be considered for warranty without a copy of the purchase receipt showing the sellers name, address and date of purchase. You must return the product to the dealer you purchased it from to initiate warranty procedures.