



2501 Ludelle Street
Fort Worth, Texas 76105-1036
817-244-6212 Phone • 817-244-4024 Fax
888-350-6588 Sales • 800-423-9696 Tech
E-mail: painless@painlessperformance.com
Web: www.painlessperformance.com

10302

MODULAR – ADD 4 CIRCUITS #1

1. Take and remove a mounting leg from one side of the main modular fuse block by sliding it back towards the wires coming out of the fuse block.
2. Install the new add-on fuse block to the side of the main fuse block by sliding it on until it snaps in place.
3. Re-install the mounting leg.
4. Secure the fuse block assembly using the four bolts, lock washers and nuts.

NOTE: The fuse block and legs fit loosely together so that once the fuse block mounting hardware has been tightened the fuse block and mounting legs will all tighten and hold each other securely in place.

5. Route the Large Red wire out to the maxi fuse holder and cut to length.
6. Strip the wire, crimp a ring terminal onto it and connect it to the maxi fuse holder terminal that has the red wire going to the main fuse block.
7. Route the Orange wire to the ignition switch, strip the wire, crimp on a terminal and connect it to the ignition switch "IGN" terminal.
8. Take and route the Blue, Purple, Red/Gry and Red/Ylw wires out to the items they are to power.

Recommended Wire Usage:

BLUE wire – Key-on Power (15 amp max load)

PURPLE wire – Key-on Power (15 amp max load)

RED/GRY wire – Key-on Power (10 amp max load)

RED/YLW wire – Constant Power (10 amp max load)

9. Cut, strip, install connector or terminal and connect to each item.

Included in this kit is a label to record what fuses are used.

**Painless Performance Limited Warranty
and Return Policy**

Chassis harnesses and fuel injection harnesses are covered under a lifetime warranty.

All other products manufactured and/or sold by Painless Performance are warranted to the original purchaser to be free from defects in material and workmanship under normal use. Painless Performance will repair or replace defective products without charge during the first 12 months from the purchase date. No products will be considered for warranty without a copy of the purchase receipt showing the sellers name, address and date of purchase. You must return the product to the dealer you purchased it from to initiate warranty procedures.

Copyright © 2007 by Perfect Performance Products, LLC